

Enabling the PCM Traces of a Port Using the Configuration Script

All Mediatrix Units

DGW 49.2.2941

2023-08-09

Table of Contents

PCM Traces	3
Requirements	4
Enabling PCM Traces of a Port Using the Configuration Script	5
Logging on to the Mediatix Unit Web Interface	6
Restarting a Service - MIPT	6
Endpoint Examples	7
Online Help	8
Available Documentation	9
Copyright Notice	10

PCM Traces

The PCM traces are two different RTP streams made specifically to record all analog or digital signals that are either sent or received by the telephony ports of the Mediatrix unit.

These RTP streams are sent to a configurable IP address, normally an IP address on your network where it can be recorded with a packet sniffer (such as Wireshark). Moreover, they are independent from the regular RTP streams of the VoIP call. On the analog devices, the streams are sent instantly at device start-up, with an average ptime of 5 ms. The resulting streams, depending on the model, are around 15 kB/s.

Only the configured port, port #1 and/or #2 send the PCM traces for a maximum of four simultaneous RTP streams.

All streams are sent instantly at start-up with an average ptime of 15 ms. This means that until the PCM traces are disabled, even an idle unit will continuously send up to $66.6 \text{ packets/s} \times 4 \text{ streams} = 267 \text{ packets/s}$ using approximately 174 bytes each, for a total of 46 Kbytes of upstream bandwidth.

On digital devices, the streams will be sent once a call is in process of being established (ISDN SETUP, SIP INVITE). This means no data will be sent if the gateway is idle with no calls in progress.

PCM Traces are usefull at identifying problems with:

- Echo in the network
- DTMF signals
- Caller ID signals
- Fax signals (or false Fax detection)
- Message Waiting Indicator signals
- Any other analog signal
- Any voice quality issue

Requirements

- RTP stream port 5001 is used for the PCM stream received from the peer.
- RTP stream port 6001 for the PCM stream sent to the peer.
- For 4400/S7/G7/C7 Series and Sentinel 100 and 400 test calls must be done on the configured port.

Note: Because of the resulting RTP traffic, enabling **Update List of Packets in Real Time** has been known to wrongly report 40% packet loss in Wireshark, which may totally impair our analysis capabilities. This feature must be disabled in Wireshark.

Note: PCM traces are not recommended in real deployments, unless it is for a short period of time, but rather in a lab environment and is meant for troubleshooting purposes only

Port names are as follows:

Ports	Names
4102S	Phone-Fax1/Phone-Fax2
C7	FXS1 to FXS8 FXO1 to FXO8
G7/S7/Sentinel 100	PRI1, PRI2, ... FXS1, FXS2, ... FXO1, FXO2, ...
Sentinel 400	Slot1/E1T1, Slot2/E1T1... Slot3/FXS1, Slot3/FXS2... Slot3/FXO1, Slot3/FXO2...

Enabling PCM Traces of a Port Using the Configuration Script

Before you start

The PCM traces destination must be set so it can be recorded in a Wireshark capture on your network, normally sent to the PC doing the capture.

Information

If a port is receiving several calls at a time, the capture will be performed on the first call until it is completed, and only then will a capture be performed on another call. Traces are taken as soon as the port is opened.

Steps

- 1) Create a txt file, and save it as a *.cfg.
- 2) Enter **Mipt.PcmCaptureEnable = Enable** or **Mipt.PcmCaptureEnable=1**
- 3) Enter **Mipt.PcmCaptureEndpoint = Value**, where **Value** is the unit's endpoint on which the PCM capture will be taken from. For more information, refer to [Endpoint Examples](#) (p.7).

Note: To make sure that you are capturing the appropriate endpoint, please verify its naming by running the following command in CLI: **Epadm.Endpoint**. The output of the command displays a table with the unit's endpoints.

Note: The port names are case sensitive.

- 4) Enter **Mipt.PcmCaptureIpAddr = Value**, where **Value** is the IP address of the PC running Wireshark.


Note: The IP address does not have to be listening on UDP ports, as it is easy to filter out ICMP "port unreachable" messages afterwards.

- 5) Import the *.cfg file into the system. Refer to [DGW Configuration Guide - Configuration Scripts Import and Export](#) published on the [Media5 Documentation Portal](#).
- 6) When the capture is done, make sure to disable the **Mipt.PcmCaptureEnable** MIB parameter.

Note: For example **Mipt.PcmCaptureEnable = Disable** or **Mipt.PcmCaptureEnable = 0**

Result

In the configuration script, the value of **Mipt.PcmCaptureEnable**, **Mipt.PcmCaptureIpAddr** and **Mipt.PcmCaptureEndpoint** parameters should reflect the values configured..



Logging on to the Mediatrix Unit Web Interface

Before you start

The computer IP address must be in the same TCP/IP network as the Mediatrix unit.

Information

For better performances, it is recommended to use the latest available version of Microsoft Internet Explorer, Google Chrome, or Mozilla Firefox.

Note: You may not be able to log on to the Mediatrix unit Web interface if you are using older browser versions.

Steps

- 1) In your Web browser, enter the IP address at which the Web interface of your Mediatrix unit can be reached.
 - If your network has an IPv4 DHCP server, connect the primary Ethernet port of the Mediatrix unit to the network (ETH1 port), use the provided DHCP server IP address.
 - You can also connect your computer to the secondary Ethernet port of the Mediatrix unit (ETH2), use the 192.168.0.10 IP address. However, the computer must also own an IP address in the 192.168.0.0/24 network.

- 2) Enter **admin** as your username and **administrator** as the password.

Note: You can also use **public** as a username and leave the password field empty; it has the full administration rights by default.

- 3) Click **Login**.

Result

The **Information** page of the Web interface is displayed.

Restarting a Service - MIPT

Steps

- 1) Go to **System/Services**.

- 2) In the **User Service** table, locate the service **Media IP Transport (MIPT)**.
- 3) From the **Startup Type** selection list next to **Media IP Transport (MIPT)**, choose **Auto** if you wish the service to start automatically when the system starts, or **Manual** to start to the service manually when needed.
- 4) In the **User Service** table, click [\[X\]](#).

Result

The tab from which you can access the Web pages are no longer greyed out.

Endpoint Examples

Endpoint Name	Description
Bri1-2	BRI port 1, channel 2
Slot2/E1T1-3	Channel 3 of the E1 port located in slot 2
Port09	Port 09 of a Mediatrix 4108-16-24 unit
Phone-Fax1	Port 1 of a Mediatrix 4102S unit
FXS1	Port 1 of the FXS card of a Mediatrix C7 unit
FXO1	Port 1 of the FXO card of a Mediatrix C7 unit

All possible endpoint names are listed in the Endpoint table displayed in the DGW Web interface (**System/Endpoints**). You may also access this table via the CLI by using the **EpAdm.Endpoint** command or directly via UMN.

Online Help

If you are not familiar with the meaning of the fields and buttons, click **Show Help**, located at the upper right corner of the Web page. When activated, the fields and buttons that offer online help will change to green and if you hover over them, the description will be displayed.

Available Documentation

For more details, refer to the [Mediatrix Documentation](#) published on the [Media5 Documentation Portal](#).

Copyright Notice

Copyright © 2023 Media5 Corporation.

This document contains information that is proprietary to Media5 Corporation.

Media5 Corporation reserves all rights to this document as well as to the Intellectual Property of the document and the technology and know-how that it includes and represents.

This publication cannot be reproduced, neither in whole nor in part, in any form whatsoever, without written prior approval by Media5 Corporation.

Media5 Corporation reserves the right to revise this publication and make changes at any time and without the obligation to notify any person and/or entity of such revisions and/or changes.



media5corp.com